Limited Edition Woven Reed Handmade Bicycle Basket



- ·Designed by Wald and handmade by Jan Treesh, a Lexington, Kentucky artisan
- ·Individually numbered, dated and signed
- ·Handlebar mounts & basket supports made by Wald in Maysville, KY

Short Screw

- · Approx. size 13" x 10" x 8 3/4" deep (each individual basket varies)
- · See mounting instructions on back



- Remove basket from holder

/!\warning

• Raise basket handle upright.

- Tighten all holder fittings securely.

DO NOT overload basket.

Pull away from holder and lift basket from bottom hooks of holder.

- This product contains a chemical known to the state of California to cause cancer.

Overloading basket may cause difficulty in steering and/or loss of bicycle control which could result in injury. DO NOT use on bicycles with a carbon fiber handlebar.

Mfgr.No.33WR ©2015 Wald LLC Rev.A, 5/14/2015

> Lower Slot for 1" & 1-1/4" Dia Bars

Upper Slot for 7/8" Dia Bars



(2) Mounting 7

Holder

HANDMADE WOVEN BICYCLE BASKET with handle & mounting holder 5 Lock End (7) Holder Slot - Basket easily removed for carrying. - Fits 7/8", 1" & 1 1/4" diameter handlebars. (3) Holder Top Bracket - Extended Mounting Holder allows clearance for shifters, brake levers & cables. ASSEMBLY INSTRUCTIONS - Loosely assemble ① brace onto two vertical side wires of ② holder with short screws. Preferably angle brace upward toward Stem as shown. (4) Handlebar Clamp - Center holder and hang 3 holder top brackets over handlebar. • If mounting to a 7/8" handlebar use upper slot on the holder 1 Brace (3) top bracket and if to a 1" or 1-1/4" handlebar, use lower slot. If clamping onto a 7/8" or 1" portion of handlebar, insert rubber spacer as shown with open end towards screw. • Loosely assemble two (4) handlebar clamps with long screws. (6) Mounting Holder Bottom Hooks - Attach basket to holder. Hold basket so (5) lock end of handle is toward holder. Center basket with holder and insert lower basket frame Spacer for 7/8" & 1" Dia Bars wire over bottom hooks of holder as shown. • Raise handle upright and insert (5) lock end of handle through (7) slot at top of holder. Long Screw Lay handle flat to lock. - Adjust holder 1 brace vertically on holder side wires until basket Open End is in proper position.