




WIRE REARFOLDING BASKET



- Use the sketch on the right to determine rack wire diameter and which size \(\mathbb{\varphi} \) clamps to use.
- For racks greater than 5/16 inch in diameter use the larger [r clamps, marked with "L".
- With latch side of basket against the rack, place the two 🖍 shaped clamps on the basket top wire (flat side of clamp toward rack), then slide clamps down onto the rack. Mount the basket toward the rear of rack to keep the heel of your foot from hitting the open basket when riding. Assemble bolts and nuts.
- · Using the "U" clamp, fasten a side basket wire near the bottom to a rack leg. Assemble with bolt as shown.
- When not in use, raise bottom up against the side toward rack, fold ends in and push front of basket flat against the latch side of basket. Fasten with ①latch, by squeezing wires together next to latch.

MARNING: Before riding, make sure your foot will not hit the open basket when pedaling.

DO NOT overload basket. Overloading basket may cause difficulty in steering and/or loss of bicycle control which could result in injury.

© Wald LLC 2016 Rev.B, 5/2/2016 Made in U.S.A. MODEL No.582 (Plated)
MODEL No.582BL (Black)
MODEL No.582WH (White)